


4KW Diesel Parking Heater

Technical Description, Installation, Operation and Maintenance Instructions



Production Type

Order No

Diesel electric DC12V/220VAC

4W2005 12C11

Version:Apr. 25, 2019

Foreword

Thank you for using our parking heater

This manual describes the technical description, installation, operation and maintenance instructions for the parking heater. To ensure the correct use of the heater please read this manual carefully before installation and use. Please keep it properly after reading it. For review.

Note:

- The contents of this manual are subject to change without prior notice, but the instructions are guaranteed to be consistent with the products purchased.
- we try our best to express the problems that users should know through the instructions. If you have questions or find something wrong, please contact us directly.
- When the user unpacks for the first time, check the main unit and accessories against the packing list. If you find any problems, please contact the dealer immediately.
- If there is a problem in use, please contact the company's marketing department or our authorized customer service station. We will be happy to help you.

Please carefully save the after-sales service warranty sheet and provide feedback as required. This sheet is the only valid proof of after-sales service.

Note:

Must be installed and used in accordance with the requirements of the manual to ensure long-term use of the product!

1.Application

FJH-4/1C-E Model air parking heater (hereinafter referred to as heater) is a special heater for caravan that integrates hot water and warm air. This heater cannot be used in bus or dangerous goods carriers.

2. Main Technical Data

Rated Voltage	DC12V		
Operating Voltage Range	DC10. 5V~16V		
Short-term Maximum Power	8-10A		
Average Power Consumption	1. 8-4A		
Fuel type	Diesel		
Fuel Heat Power (W)	2000	4000	5000
Fuel Consumption (g/H)	220	440	550
Quiescent current	1mA		
Warm Air Delivery Volume m3/h	287max		
Water Tank Capacity	10L		
Maximum Pressure of Water Pump	2. 8bar		
Maximum Pressure of System	4. 5bar		
Rated Electric Supply Voltage	~220V		
Electrical Heating Power	900W	1800W	
Electrical Power Dissipation	3. 9A	7. 8A	
Working (Environment)	-25℃~+80℃		
Working Altitude	≤1500m		
Weight (Kg)	15. 6Kg (without water)		
Dimensions (mm)	510×450×300		
Protection level	IP21		

Table 1

3. Function

The heater is a hot water and warm air integrated machine, which can provide domestic hot water while heating the occupants. This heater allows use during driving. This heater also has the function of using local electricity heating.

In hot water warm air work mode, this heater can be used to heat both the room and the hot water. If only hot water is needed, please choose hot water working mode.

When the ambient temperature is below 3° C, please empty the water in the water tank to prevent freezing of the water tank.

There are three energy options to choose from:

--- Diesel Mode

Heater automatic adjust the power.

--- Electrical Mode

Manually select the 900W or 1800W heating mode according to the power supply capacity of the RV camp site.

--- Hybrid Mode

When the power demand is low (for example, maintaining the room temperature stage), the electrical heating is preferred. Until the city electricity cannot meet, the diesel heating is started, and the diesel heating function is turned off first in the power adjustment phase.

In hot water working mode, gas mode or electrical mode is used to heat the tank. The tank temperature can be set to 40° C or 60° C.

--- Diesel Mode

The heater operates at the lowest power. Stop heating immediately after reaching the set temperature.

--- Electrical Mode

Manually select the 900W or 1800W heating mode according to the power supply capacity of the camp site.

4. Safety work environment

-- The device can only be operated with appropriate control panels and accessories

--Danger of toxic exhaust fumes. The heater's exhaust can be toxic in enclosed spaces (e.g. garages, workshops). If the vehicle is parked in closed rooms: Shut off the fuel supply to the heater. Deactivate the time switch. Switch off the heater at the control panel.

--If the cowl has been placed near or directly beneath an opening window, the appliance must be equipped with an automatic shut-off device in order to prevent operation with the window open.

--Heat sensitive objects (e.g. spray cans) or flammable materials/liquids must not be stored in the same compartment where the appliance is installed because under certain conditions, this area may be subject to elevated temperatures.

--The openings for circulated air intake, the installation compartment and the space around the unit must be kept free of obstacles so that the unit does not overheat.

--Keep the cowl for the exhaust duct and combustion air intake free of contamination (slush, ice, leaves etc.) at all times.

Danger from hot surfaces and exhaust gas. Do not touch the area around the wall cowl and do not lean any objects against the wall cowl or the vehicle.

Obligations of the operator/vehicle owner

--The operator is responsible for the water with which the boiler is filled and for its quality.

--The vehicle owner is responsible for correct operation of the appliance.

--Liquid fuel system must comply with the technical and administrative regulations of the respective country of

use. The national legislation and regulations must be observed.

--Pressure regulating devices and hoses must be replaced with new ones no more than 10 years after their date of manufacture (every 8 years if used commercially).

--Inspect hose lines regularly and have them replaced if they are broken.

--If the heater is not being used, always drain off the water if there is a risk of frost. NO claims may be made under the warranty for damage caused by frost.

Safe operation

--The flow rate of the pressure regulating equipment must correspond to at least the maximum consumption of all devices installed by the system manufacturer.

--Ensure that the inside of the vehicle is sufficiently ventilated when the unit is started up there may be some smoke and/or smell due to dust or dirt. Especially if it has not been used for a long time.

--This appliance can be used by children aged 8 and over, as well as by persons with reduced physical.

--The integrity and tight fit of the exhaust double duct must be checked regularly, particularly at the end of long trips. Also check the mounting of the unit and the cowl.

--When cleaning the vehicle, do not spray water directly into the cowl.

5. Heater installation

The typical installation of the heater is shown in figure1.




Figure 1

- 1-LCD control switch
- 2-External temperature sensor
- 3-Recirculating air inlet (minimum 150cm2)
- 4-Heat pipe
- 5-Heat outlet
- 6-Smoking cowl




Figure 2

★ Must be installed and repaired by professionals authorized by the company!

The company does not bear any responsibility for the following acts:

- Modified heater and accessories
- Modification of exhaust lines and accessories
- Do not follow the operating installation instructions
- Do not use our company's special accessories

- 1-LCD switch
- 2- External temperature sensor
- 3-Cold water inlet
- 4-Hot water outlet
- 5-Fuel connection
- 6-Warm air outlets
- 7-Circulated air intake
- 8-Exhaust discharge
- 9- Combustion air inlet
- 10-Electronic control unit
- 11-Water container
- 12-Burner
- 13-Heat exchanger
- 14-Power electronic
- 15-Heating elements
- 16-Overheating switch

Heater installation Figure 3.




Figure 3

1_12V Power cord 2_LCD switch Lead wire 3_LCD switch back cover 4_LCD switch bracket 5_Self-tapping screw M3*10 6_LCD control switch 7_Cross countersunk head flat tail self-tapping screw M3*6 8_Self-tapping screw ST5*25 9_Heater 10_Controller cover 11_External temperature sensor lead wire 12_External temperature sensor 13_Fuel pump connector 14_Fuel pump 15_Fuel pipe clamp (ϕ 9-11) 16_Damper 17_Fuel pipe connector 18_6-Fuel pipe (transparent, from heater to fuel pump) 19_Fuel pipe clamp (ϕ 8-10) 20_Fuel pipe (blue, from fuel tank to fuel pump) 21_ ϕ 10 Steel (water) pipe elbow transition fitting 22_Hose (water) transition fitting 23_Intake pipe mounting clamp 24_Self-tapping screw ST3.5 \times 25 25_Air intake pipe 26_German type clamp 27_Exhaust pipe 28_Sealing rubber spacer 29_(Exhaust pipe) clamp 30_Intake and exhaust combine cow 31_Intake and exhaust combine cover 32_Air outlet 33_Hot air ducting 34_Ducting clamp 35_ ϕ 60T-pipe 36_ ϕ 60 connector 37_ ϕ 60 Elbow 38_G1/2- ϕ 10 Ferrule fitting 39_Frost valve 40_G1/2 T pipe 41_Reducing valve 42_Filter 43_Fuel suction pipe 44_Self tapping self drilling screw ST5*30

A_Connect to 12V Battery B_connect to water equipment C_connect to system water tank

D_Flow out of the car E_Hook, clamp LCD switcher cord

The heater installation location should be selected from load-bearing floor, double floor or underfloor.

If there is no suitable floor, you can first make a load bearing surface with plywood.

★The heater must be firmly fixed to the mounting surface with

screws to prevent damage to the gas pipeline during driving and cause danger.

Depending on the actual installation, may only install three screws. Two die-cast aluminum fixing screws are fixed then choose a plastic right angle to fix it.

To ensure that the heater evenly distributes heat, the heater

should be installed in the center as much as possible to ensure that the heating circuit is equal long as possible.

No cover is allowed to add to the heater surface.




Figure. 4

The size with* is the smallest size, leaving enough space to connect accessories such as gas and water pipes.

To prevent the danger from heater accidentally loosening, the upper cover of the heater compartment is screwed to the upper cover (Figure 4-1). Next to the installation location it is necessary to install a strong partition strip in front of the heater, perpendicular to the direction of travel. Above the floor height180mm can be attached to a septum (minimum 30*50mm).

Heat sensitive objects and flammable objects should be placed away from the heater.




Figure. 5

★ The exhaust cowl must be on the side wall or ceiling.

In the exhaust cowl installed area, there is no ventilation window in the range of 300mm, and there is no refueling port or tank respirator in the range of 500mm.

The exhaust cowl is mounted below the window that is close to or operable. A window switch should be installed to ensure that the heater is turned off automatically when the window is opened.

Air Inlet Hose Installation

The exhaust pipe is passing through the intake pipe. The length of the intake and exhaust pipe is as shown in Fig. 6, and the shortest is 60cm and the longest is 100cm. The exhaust cowl is only allowed under the exhaust outlet 20cm.




Figure. 6

After the intake and exhaust pipes are pierced from the through holes, they must be cut short, and the exhaust pipes are slightly shorter than the intake pipes. Avoid excessive expansion or tension on the exhaust pipe




Figure. 7

The length of the intake and exhaust pipes is 100 cm to 200 cm, as shown in Figure 7. The piping must be arranged in the ascending direction.

The Exhaust Cowl (air inlet and outlet) Installation

Select a flat mounting surface so that combustion air can enter from all sides. Drill one hole of $\phi 83$. Seal (Fig. 8-8), with the plane facing the exhaust cowl. Wear the fixing clip before installing the exhaust pipe (Figure 8-3). Pay attention to the installation of the smoke cap upwards. 20mm at the end of the exhaust pipe should be compressed, do not straighten. Insert the exhaust pipe into the exhaust cowl interface (Figure 8-10) , as deep as possible. Try to fix the clips on the top, tighten.




Figure. 8

Place the air intake pipe (Figure 8-2) over the exhaust cowl tooth (Figure 8-11). Set on the fixed clip (Figure8-7) , tighten.

Secure the exhaust cowl with 6 screws (Figure 8-9). Use 2 screws to fix the exhaust cowl.

Fix the exhaust pipe on the side wall with mounting clip.

Connect Air Inlet Pipe to The Heater




Figure. 9

20mm at the end of the exhaust pipe should be compressed, do not straighten.

Try to insert the exhaust pipe on exhaust port as deep as possible. fix the clip on top, tighten.

Place the air intake pipe (Figure 9-3) over the air inlet port (Figure 9-5). Set on the fixed clip (Figure9-6) , tighten.

Warm Air Intake




Figure. 10

The warm air intake is drawn in by the heater. There must be a total area between the room and the heater not less than 150cm2 opening.

Ensure that the warm air intake is not contaminated by the engine or heater exhaust, if necessary, with structural isolation measures.

Warm Air Distribution

Most of the warm air is imported into the floor area of the living compartment through the bellows.




Figure. 11

The four air outlets on the heater are connected to the $\phi 65$ bellows. Use only pressure piping that meets the quality requirements of the Belief. Other pipes that do not meet our quality standards (especially wind resistance, pipe diameter

and number of ripples) shall not be used. If the warm air duct must withstand a considerable amount of bending immediately after the hot air outlet of the heater in a limited space, we recommend using a 90° elbow (Figure 3-37). This elbow can be connected to a diameter of 65mm hot air duct.




Figure. 12

In the case where the length of the pipe is less than 2 meters the air outlet cannot be installed at a height Fuel tank the connection of the warm air duct. When the pipe length is less than 50cm, the pipe must be siphon between the connector and the outlet. These measures prevent the undesirable heating caused by (fairing effect) convection of the vehicle during summer operation.

- ★The warm air pipe must be firmly inserted into the connection port.
- To get the best warm air distribution, Belief recommends using 4 warm air outlets for the heater.
- If only three warm air outlets are required, then a lower warm air outlet must be selected to seal.

- ★ The cross section of the heater duct must not be reduced due to pipe connections or the analogue.
- In other words, no less than four warm air outlets (figure 3_32) are opened. Make sure that more than four warm air outlets are opened.

Fuel system connection

The fuel is extracted from the vehicle fuel tank or supplied from the 10L special fuel tank. The fuel is transferred and the fuel supply is adjusted through the special fuel pump (provided by the manufacturer).Fuel extraction from the vehicle engine return system or downstream of the vehicle internal delivery pump is not permitted. Please install only the fuel hose and piping within the delivery range.

The fuel shall meet national standards
GB19147-2013 diesel standard for vehicles

Winter fuel should meet the low temperature requirements brand, do not allow the use of biofuels.

Fuel line system




Figure13

Installation of oil pipe

Only the flexible nylon pipe, which has good light-resistance and thermal stability, supplied with the heater can be used as the fuel pipe. Allowable length of fuel line: the maximum length of fuel line on the inlet side is 2 meters, and the maximum length on the pressure side is 6 meters. As shown in figure 13.

Safety Regulations for Fuel Pipe

Use a hose cutter or sharp cutter to cut the fuel hose and pipeline into a certain length. The cut area cannot be compressed and must be free of burrs. Fuel pipelines must be firmly connected to prevent vibration-induced damage or noise (the recommended distance between connecting points is about 50 cm). Fuel pipelines must be protected from mechanical damage. The laying of fuel pipelines will not adversely affect the stability of vehicle rotation and engine operation. Protect fuel-carrying parts from high temperatures that may affect operation (use appropriate glass fiber lined aluminum thermal protection hoses). Do not install or fix fuel lines near the exhaust pipes of heaters or vehicle engines. If the lines are crossed, keep enough distance from the thermal components – provide a thermal radiation shield if necessary. Pipe installation should be able to prevent flying stones from hitting, and keep away from heating parts of vehicles. Protective devices should be installed when necessary.

Installation of oil pump

The oil pump shall be fixed with a fixed jacket (rubber) of the oil pump. The outlet of the oil pump should be inclined upward, and its installation angle should be selected in the range of 15- 35 as shown in Figure 14. When conditions permit, the tubing between the pump and the heater mainframe should gradually rise. In order to prevent the oil pump from being heated (the maximum operating temperature is 40 C), do not install it near the exhaust pipe.

The height difference between the fuel level and the oil pump, and the height difference between the oil pump and the main engine inlet, will generate pressure (or suction) in the oil pipeline, so these dimensions should meet the requirements of Figure 14 (negative pressure will occur in the closed tank, when the minimum liquid level of the tank is required to be no more than 0.4m).

Connection between heater and oil pump

The pipeline from the oil pump to the main engine should go up as far as possible. Mark the appropriate position on the floor of the vehicle for passage the hole of the fuel pipeline and the oil pump connecting the cable. Before drilling, pay attention to check the hidden cable, fuel pipeline, frame section, etc.




Figure14

The lower body protection device is then used to seal the edges of the openings on the floor of the vehicle. In order to prevent the cable between the tubing and the oil pump from being cut, please add the lead-in bushing or section edge protection material. The tubing should be bundled at the appropriate place for fixing, and the bundling distance is not more than 50 cm.

Connections between tubing and oil pump, main engine and oil tank (oil intake nozzle) shall be made by using tubing joints matched by this unit and using oil. The pipe clip is clamped tightly. Prevent bubbles from forming at the junction (Pic. 15).




Figure 15

Installation of Fuel Filter

Install the fuel filter before the oil inlet of the oil pump.

When installing, it should be noted that the fuel filter must be vertical upward (to ensure that impurities deposit downward). Fuel filter replacement cycle for two years, tubing connection head and clip must be replaced at the same time.




Figure16

Installation of oil intake nozzle (Pic17)

Firstly, the oil intake nozzle is fitted with O-ring, and then it passes through the bottom hole (self-processing) through the inside of the tank. Put gaskets on the outside of the tank and tighten them with nuts. The tightening torque is $6\text{Nm}+1\text{Nm}$. The O-ring must be clamped between the inner wall of the tank and the oil intake nozzle to ensure good sealing between the

oil intake nozzle and the oil tank. (Accessories such as oil intake nozzles are attached to the tank)




Figure 17

Installation of suction pipe (Pic21)

Use when drawing fuel from the fuel tank of the vehicle itself.

When installing, attention should be paid to the size of the installation hole on the tank (or the cover of the tank) is $25 (+0.2)$, the edge is neat and the surrounding is smooth, so as to ensure good sealing between the suction pipe seat and the tank. The distance between the bottom of the suction pipe and the bottom of the tank should be $30-40\text{ mm}$, which can not only ensure the full absorption of fuel, but also prevent the deposition of impurities at the bottom of the tank from being inhaled.




Figure18

The connection of water pipe

A pressure pump or submerged pump with a pressure of 2.8 bar can be used to supply water to the water tank. If the water

tank is connected to a centralized water supply (rural or urban connection), or if a high-pressure pump is used, a decompress or must be used, which will prevent pressure above 2.8 bar.

★Before the relief valve is triggered, the temperature rise and expansion of the water may cause up to 4.5 bar of pressure (which may also occur with the submerged pump). Water pipes connected to water tanks and safety/drainage valves must be safe for drinking water, pressure-resistant (up to 4.5 bar) and hot water resistant up to 80° C. Antifreeze valve (Pic3-39, Freeze-proof automatic water discharger), A mechanical safety/drainage valve. When there is a danger of frost, it will automatically drain water from the tank through the drain.

Pressure relief valves must be installed (Pic3-41, 0.5MPa). If there is too much pressure in the system, the pressure will automatically be released intermittently through the relief valve.

Installation of External Temperature Sensor

Install the car and measure the room temperature. The installation position of the sensor is determined by the manufacturer of the RV according to the specific conditions of the vehicle. When choosing the installation location, please note that the external temperature sensor should not be subjected to direct thermal radiation. In order to obtain the best room temperature control, an external temperature sensor is installed above the entrance door.




Figure19

Make sure that the external temperature sensor is always mounted on the vertical wall. It must be surrounded by free-flowing air.

Drill a hole 10 mm in diameter. The single-wire terminal passes through the opening from the back and connects the end of the cable to the sensor with an insulating plug (without observing polarity). Slide into the external temperature sensor and connect the two ends of the cable with two insulating connectors to the heater electronic devices (if necessary, extend the cable to a maximum length of 10 meters, 2 *0.5 mm 2 cable). The external temperature sensor provided must always be connected, otherwise the heater will switch to failure.

Install LCD switch

Gas heater must be operated by special liquid crystal switch. See the relevant instructions for details.





Figure20

Electrical Connection

Lay wires to avoid scratches. If there are sharp edges, such as metal panel threading, please use lead bushing or edge protection accessories. Connector cables shall not adhere to or touch metal surfaces, exhaust pipes or hot air pipes. The electrical connection socket is located below the controller cover. The controller cover can be removed by pressing and sliding along the arrow at the same time. When removing or installing the controller cover, make sure that the connecting cable is not pulled out or squeezed.



- 1- DC12V positive electrode
- 2- DC12V negative electrode
- 3- Fuse
- 4- Window Switch
- 5- External temperature sensor
- 6- 7-control switch

Pic21

When the window switch is not installed, the short wiring cannot be removed. All cables connected to the heater should be poked in a sagging direction. This prevents condensate from slipping off the connector cable and entering the heater.





Figure22

Connector cables and plugs must not be subjected to force.

(Pic19), Tie connector cables and fasten them to the housing with straps to eliminate tension.

All cables must be firmly connected together. They should not be loosened or disconnected by vibration, resulting in fire hazards!




Pic23

DC12V Power


The electric circuit, switch and control equipment of the heater must be located in a position that will not adversely affect its operation under normal working conditions. The heater has reverse polarity protection. If the controller is not properly polarized, the LED indicator will not work.

In order to provide the best power supply, the heater must be connected to the on-board power supply (or battery) protected by fuse (10A) with a 2 x 2.5 mm 2 cable (2 x 4 mm 2 for a length exceeding 6 m). If necessary, the voltage drop of the power supply line must be considered. Connect the negative pole line to the main grounding. If the heater is directly connected to the battery, the positive and negative lines must be protected. Do not connect other power-consuming equipment.

Electrical connection of oil pump



Make sure the plug is firmly connected.



6. Operating precautions

Heaters are not allowed to operate during refueling or in enclosed spaces (enclosed parking lots, repair shops or ferry compartments). Check regularly whether the intake and exhaust pipes are in good condition and the fixing is reliable, especially after a trip. Also check the fixing of intake and exhaust pipes and smoke caps.

When black smoke is found, the company's authorized professionals are requested to carry out the inspection. Ensure that the exhaust pipe and intake pipe at the smoke exhaust cap are free from blockages such as snow, ice and leaves. Warm air outlet and circulating air inlet are unobstructed to avoid overheating of heater. In the case of overheating, the overheating switch will immediately cut off the fuel supply.

If the fuel heater wants to meet the heating needs in driving, it should install safety shut-off device.

★ If there is no safety shut-off device, the heater must be turned off before driving.

12V Fuse

Replacement with exactly the same fuse T20A is allowed only.




Figure25

~220V Fuse

★ Fuses and wiring harnesses must be replaced by

professionals authorized by the Company.

★ All power supply must be disconnected before opening the control housing.

Fuse Specification: T10A Slow Fuse




Figure26

~220V Overheat protection

The municipal electric heating function has a mechanical overheating protection switch. If the 12V power supply is interrupted during or after the heating process, the excess heat of the heater will trigger the overheating protection switch.

When the temperature of the water tank decreases, disconnect the power supply from 220V, remove the cover of the controller, and reset the overheat protection switch by pressing the reset button by hand. .




Figure27

7. Operational instructions

Please read the instructions carefully before operation.

Start-up heater

Use special liquid crystal switch to operate.

Fuel oil, electricity, mixing mode, heating water tank or unheated water tank for main engine heating are set according to need.

Check the power supply capacity of RV camps, and choose the operation mode of 900W (3.9A) or 1800W (7.8A) accordingly.

--Check whether the smoke exhaust cap is unobstructed

--Open Liquefied Gas Tank Switch Valve

--The tank is full of water when needed

Filling of water

Check whether the relief valve/drain valve is closed.

——Turn on the pump power supply (main gate or pump switch)

——Open the hot water tap in the kitchen or bathroom and keep the valve open until the air in the container is discharged and the water is continuously discharged.

——In the absence of water heater heating, if only the cold water system is in operation, the water heater will also be full of water. To avoid frost damage, the water heater must be drained through a safety/drainage valve, even if it is not running.

——In the case of frost, the frozen residual water can prevent filling. The water heater can thaw (no more than 2 minutes) if it is turned on for a while. The ice can be thawed through the inside of the heater.

——If the heater is connected to the central water supply system (rural or urban water supply system), a pressure reducer must be used to prevent pressure exceeding 2.8 bar (0.28 MPa).

--Open the circulating pump

--Open the hot tap in the kitchen and bathroom until the air is exhausted and the water tank is filled, and the water is

not interrupted.

Turn off the heater

--Use special liquid crystal switch to operate.

--After the heater is closed, the combustion-supporting fan and heating fan will continue to work for several minutes according to the temperature of the furnace body.

In case of freezing danger, it is necessary to ensure that the water tank is emptied.

—Close the circulating pump

—Turn on the hot tap in the kitchen and bathroom

Heater drainage

——If the RV is not used during the frost. The heater must drain the water.

——Turn off the power supply (main power supply or pump switch) of the pump unit.

——Turn on the hot tap in the kitchen and bathroom.

——In order to check the effluent, the safety/drainage valve (user-fitted, for manual emptying of the water tank) is installed. The anti-freeze valve cannot ensure that the water tank is completely emptied. Place a suitable container under the drain tank.

——Open the safety/drainage valve.

——The heater will be discharged directly to the outside through the safety/drainage valve. Check whether all water in the heater has been discharged into the container through the safety/drainage valve. Claims for damage caused by frost shall not be filed during the warranty period.

★The 10L bucket can be used for water inspection to ensure that the water tank is empty.

The valve of liquefied gas tank must be closed before heater is not used for a long time or running.

Maintenance/repair/cleaning

--The device can only be repaired and cleaned by experts.

--Maintenance, repair and cleaning cannot be done by

children.

--With new equipment, or the equipment has not been used for some time, thoroughly flush all hot/cold water hoses before use.

8. Failure

8.1 General Failure Handling

8.1.1 During the use of the heater, it may appear that it cannot start normally or turn off it after starting and is in the fault lock state. At this time, the heater can be turned off for more than 5S and restart.

8.1.2 The heater may cause circuit failure due to the following reasons: the connector is rusted, the poor contact, the plug is incorrect, the wire or fuse is rusted, the battery pile is rusted, etc.

Pay attention to inspection, maintenance and prevent these phenomena from occurring during use.

8.1.3 When the following conditions occur, it can be handled and eliminated by the user:

● The heater does not start after the power is turned on and the LCD switch screen does not light. The reason is that the fuse is open, or the wiring is wrong. In addition, check whether the plug on the LED switch lead wire is properly connected to the host.

8.2 Fault Lock Status

8.2.1 The fault generated by the heater is indicated by the fault code on the LED switch.

8.2.2 The faults can be eliminated according to the methods Listed in Table 2.

Fault Lock Status Debug Method

Fault Code	Fault Name	Fault Debug Method
10	Overvoltage fault	a. Check vehicle power supply system
11	Under voltage fault	a. Check vehicle power supply system
21	Warm air outlet temperature sensor disconnection	a. Check if the sensor is in good condition
22	Warm air outlet temperature sensor short circuit	a. Check if the sensor is in good condition
23	Water temperature sensor disconnection	a. Check if the sensor is in good condition
24	Water temperature sensor short circuit	a. Check if the sensor is in good condition
25	External temperature sensor disconnection	a. Check if the sensor is in good condition
26	External temperature sensor short circuit	a. Check if the sensor is in good condition
27	Combustion support temperature sensor disconnection	a. Check if the sensor is in good condition
28	Combustion support temperature sensor short circuit	a. Check if the sensor is in good condition
31	Combustion failure	a. Check gas supply system b. Check whether combustion inlet and outlet are blocked c. Check the Ignition coil, ignition electrode, d. Flame sensor
32	Combustion failure	a. Check gas supply system b. Check whether combustion inlet and outlet are blocked c. Check the flame sensor
33	Flame sensor fault	a. Check the flame sensor lead wire Check the flame sensor
41	Warm air outlet overheats	a. Check whether air outlet is blocked
42	Warm air overheats switch protection	a. Check whether air outlet is blocked b. Check warm air overheat switch
43	Water overheat	a. Check whether water depletion in the tank b. Check if the sensor is in good condition c. Check whether air outlet is blocked

Fault Lock Status Debug Method		
Fault Code	Fault Name	Fault Debug Method
44	Warm air overheats switch protection.	a. Check whether air outlet is blocked. b. Check warm air overheat switch
45	Overheating fault	a. Check whether air outlet is blocked b. Check water temperature sensor c. Check warm air sensor
51	Communication fault	a. Check interconnecting cable
61	Oil Pump Break	a. Check whether the oil pump lead is damaged or not b. Check whether the connection of oil pump leads is reliable. c. Refurbishment oil pump d. Replacement of motherboard
62	Short circuit of oil pump	a. Check whether the oil pump lead is damaged b. Check whether the connection of oil pump leads is reliable c. Refurbishment oil pump d. Replacement of motherboard
63	Circuit Breaking of Electric Plug	a. Check the power supply voltage b. Check the resistance of the plug at room temperature (0.2/12V) c. Cleaning up Carbon Accumulation in Electric Plug d. Replacement of motherboard
65	Electric plug without drive	a. Replacement of motherboard
81	Combustion support fan disconnection	a. Check combustion air blower
82	Combustion support blower boot failure	a. Check the blower motor lead wire b. Check combustion air blower
83	Combustion support blower spindle speed too low	a. Check combustion air blower motor
84	Warm air blower motor disconnection	a. Check warm air blower motor
85	Warm air blower motor boot failure	a. Check the blower motor lead wire b. Check warm air blower motor
86	Warm air blower spindle speed too low	a. Check warm air blower motor
110	Window alarm	a. Check window switch interconnecting cable
120	Low voltage alarm	a. Recommended charging
220	220V Connectionless	a. Check AC 220V power supply system

Table 2 to continue

9. Operational Precautions

●Initial Installation

— The heater is installed for the first time. In order to completely eliminate the air in the fuel supply system and make the fuel pipeline full of fuel, a separate pump function is specially designed. See LCD switch instructions for details.

— Rinse the water tank with clean water before the heater is first installed and used. When the heater is not in use, please empty the water tank so as not to freeze the water tank. The company is not liable for damage to the water tank caused by freezing.

— Open the circulating pump

— Open the hot tap in the kitchen and bathroom until the air is exhausted and the water tank is filled, and the water is not interrupted.

— The heater should be tested before use. During the trial run, all connections should be carefully checked for leaks and security conditions. If there is smoke emission, abnormal combustion noise or fuel gas odor, the heater should be closed and the fuse should be pulled out so that it cannot operate. It can only be used after being inspected and repaired by professionals.

— When the heater is first used, it may emit odor in a short time. This is normal in the first few minutes of operation, and it does not mean that the heater is out of function.

●Quarterly Maintenance

— Before each heating season, the following maintenance work must be carried out by professionals:

Check whether the air inlet and outlet are contaminated and foreign matter.

Clean the outside of the heater.

Check for corrosion and loosening of circuit joints.

Check whether the intake and exhaust pipes are blocked or damaged.

Check the fuel line for leakage.

●Long-term shutdown

— When the heater is not used for a long time, it should be run every 4 weeks for about 10 minutes each time to prevent mechanical parts such as solenoid valves and combustion-supporting air fans from failing to function (freezing).

— The inlet and outlet of heater must be kept free of blockage and dirt, so that the warm air duct is unimpeded, in order to prevent overheating failure.

— When replacing low-temperature fuel, the heater should run for at least 15 minutes to fill the fuel system with new oil.

●Heater life

— The heat exchanger of the heater cannot be used for more than 10 years. Upon expiration, it must be replaced by genuine parts and replaced by the heater manufacturer or its authorized agent.

— When the exhaust pipe of the heater discharges combustion exhaust gas for 10 years, it must be renewed with genuine parts.

●Other considerations

— **Water tanks must be cleaned regularly, at least twice a year.**

— In the process of transportation and storage, the ambient temperature of heater should not exceed the range of $-40 \sim 85^{\circ}\text{C}$ in order to prevent damage to electronic components.

— Only authorized customer service stations are allowed to install and repair heaters, and non-original parts are prohibited to avoid danger.

— The manufacturer is not responsible for the maintenance of the heater due to the failure to install and operate in accordance with the regulations.

— The heater must be turned off before refueling.

— When welding automobiles, the positive pole of the heater should be removed from the battery and grounded to prevent damage to the controller.

10. Packing list

Packing list				
No.	Name	Specifications	No.	Order code
1	Instructions	YFJH-6E/1C main engine	1	22020203400
2	Heater mainframe	YFJH-6E/1C	1	4T300612C01
3	Cross head tapping nail	ST5*25	5	12050016100
4	12VPower cord	4m	1	12031101600
5	External temperature sensor	NTC10K	1	31011102100
6	External temperature sensor lead	L=4m	1	12031100500
7	LCD Switch	MNB-V-FY	1	31011104400
8	Instructions	LCD Switch MNB-V-FY	1	22020202600
9	Cross head tapping nail	M3*10	4	12050002400
10	Cross countersunk head and flat tail self-tapping nail	M3*6	1	12050016000
11	LCD Switch Lead	6m	1	12031101500
12	Controller Cover	260×75×22	1	12021100900
13	Cross head tapping screw	ST5×16	4	12050007300
14	External wire clamp sleeve connector	G1/2-φ10	2	12011104300
15	cable ties	4×200	10	21990000000
16	Intake and exhaust body	φ110×108	1	12011101900
17	Intake and exhaust hood	φ110×34	1	12021102000
18	Gasket	φ104.5×φ73×2.4	1	12041101800
19	Clamp	φ55	2	31011102700
20	German clamp	70-90	2	12050200700
21	Fixed clip for intake pipe	φ80	1	12021102700
22	Cross head tapping screw	ST3.5×25	9	12050015600
23	Exhaust pipe	φ55/φ50×950	1	12060007700
24	Intake pipe	φ80/φ76×1000	1	12060007800
25	Vent	CFK-φ60-III(Flexibility adjustable)	4	31011104700
26	Pressure relief valve	0.5MPa	1	12501101000
27	Antifreeze valve	1~4℃	1	31011106600
28	German clamp	φ50-φ70	4	12010005100
29	Bellows snap	φ60	4	12021102600
30	Oil Pump Assembly	YB- I -12V Buffer	1	33000007600
31	Fixed jacket of oil pump	φ32×29	1	12990007300
32	Oil Filter Assembly	CX0708(4100)Aluminum base and combination cushion	1	12500005400
33	Tubing joint	φ3.5/φ9.5 L=40	3	12060003900
34	Tubing joint	φ4.1/φ10.5 L=40	4	12060003800
35	Tubing clip	φ8~10 (9)	5	12010004300
36	Tubing clip	φ9~11 (10)	9	12010004200

Packing list				
No.	Name	Specifications	No.	Order code
37	Pipeline (oil pump to main engine)	Nylon pipe $\phi 4 \times 1$ L=6800 transparent	1	12060004200
38	Pipeline (pump to tank)	Nylon pipe $\phi 5 \times 1.5$ L=1200blue	1	12060004600
39	Unidirectional valve	4*36	1	Encoding
40	Oil pump wiring harness	L=6800	1	12031200300
41	Self-drilling and self-tapping screw	ST5.5 \times 30	3	12050003000
42	Suction pipe	XYG-II $\phi 5 \times 600$	1	31000000500
43	Reducing T	10-6-10	1	12020015700
44	Mini Clamp	12-14	2	12010004600

Note: Items 16 to 44 are separately packed in attachment boxes.

Outside the packing list are optional accessories, which can be selected by contacting us.